

pHTestrs® 10, 20, and 30

Our most popular pHTestr® offers a larger display, with more information to make measurement easier

Unique double-junction electrode design – For significantly longer electrode life, especially in harsh applications like wastewater, plating baths, life science, and food

Waterproof, dustproof housing – IP67 rated, maintains the integrity of your tester even in dirty or damp field conditions. Plus, it floats!

Replaceable electrode module – Reuse the same meter body for cost savings

Push-button calibration with auto-buffer recognition

Automatic temperature compensation (ATC) – Gives you accurate readings even with fluctuating temperatures

Hold function – Freezes reading so that you can record it

Self-diagnostic error messages – Make troubleshooting easier

Auto shutoff – Extends the life of the batteries

pHTestr 10 features – Three-point calibration, ±0.1 pH accuracy

pHTestr 20 features – Three-point calibration, ±0.01 pH accuracy

pHTestr 30 features – Three-point calibration, ±0.01 pH accuracy, and simultaneous temperature display



All Oakton® waterproof pHTestrs float!



Large LCD display



35634-30 Waterproof double-junction pHTestr 30

ISO9001:2000
CERTIFIED SUPPLIER



1 year warranty
meter only

Specifications

Model	pHTestr 10	pHTestr 20	pHTestr 30
Range	-1.0 to 15.0 pH	-1.00 to 15.00 pH	-1.00 to 15.00 pH
Resolution	0.1 pH	0.01 pH	0.01 pH
Accuracy	±0.1 pH	±0.01 pH	±0.01 pH
Temperature display	—	—	0 to 50°C (32 to 122°F)
Calibration	Three point at either pH 4.0, 6.86/7.0, or 9.18/10.0		

Temperature compensation: automatic (ATC), from 0 to 50°C (32 to 122°F)

Operating temperature: 0 to 50°C (32 to 122°F)

Special functions: On/Off or Auto-Off after 8.5 minutes; Hold; Calibrate and Confirm

Power: four 1.5 V alkaline batteries (included), >500 hours continuous use; Eveready® A76 or LR44 equivalent replacement

Dimensions

Unit only: 6½" x 1½" dia (16.5 x 3.8 cm)

Boxed: 7¼" x 2½" x 2" (18.4 x 6.4 x 5.0 cm)

Weight

Unit only: 3.25 oz (90 g); **Boxed:** 4.5 oz (125 g)

Ordering Information

Catalog number	Description	Included
WD-35634-10	pHTestr 10	Tester, detachable electrode sensor, and batteries
WD-35634-20	pHTestr 20	Tester, detachable electrode sensor, and batteries
WD-35634-30	pHTestr 30	Tester, electrode, detachable electrode sensor, calibration buffer pouches, and batteries

WD-35624-38 Replacement electrode sensor for pHTestr 10, 20, and 30

WD-35634-70 pHTestr 10 calibration kit includes Testr, calibration buffer pouches (two each of pH 4.01, 7.00, 10.00 and rinse water), sample jar, and sturdy carrying case

WD-35634-80 pHTestr 20 calibration kit includes Testr, calibration buffer pouches (two each of pH 4.01, 7.00, 10.00 and rinse water), sample jar, and sturdy carrying case

WD-35634-90 pHTestr 30 calibration kit includes Testr, calibration buffer pouches (two each of pH 4.01, 7.00, 10.00 and rinse water), sample jar, and sturdy carrying case



Water Treatment



Laboratory



Industrial



Food